




# GORE® Sealant Technologies

## Joining Techniques



### GORE® Series 500 Gasket Tape

SKIVE CUT at starting bolt hole



Tape Thickness (t)	Skive cut length (ls)	Maximum height (h)
1/8 in (3 mm)	3/4 in (15 to 20 mm)	3/16 in (3.5 to 5 mm)
1/4 in (6 mm)	1-1/4 in (25 to 40 mm)	3/8 in (6.5 to 9 mm)



No valley



No step



No double thickness




### GORE® Joint Sealant

OVERLAP both ends at starting bolt hole




#### Standard Flanges


#### Fragile Flanges




Flat Faced



**Option 1:**  
To prevent flange rotation.



Raised Faced



**Option 2:**  
To minimize flange rotation.

The skive cut technique is recommended to complete the gasket when 5/8 in (17 mm) or wider GORE® Joint Sealant is being used, except when installed on ASME or JIS metallic flanges.