

## **GORE® Gasket Tape Series 500**

### **Saves You Time, Money and Trouble**

#### ***Fits any shape instantly & reliably***

The user creates a gasket instantly in any shape, regardless of flange size or complexity, and, plant reliability and safety improves too with recently patented technology.

This exceptionally creep resistant 100% expanded PTFE (ePTFE) form-in-place gasket tape delivers worry-free sealing performance for large steel flanges, especially those with thermal cycling.

GORE® Gasket Tape Series 500, at least 50% greater creep resistance than other ePTFE gasket tapes, maximizes gasket stress, retains bolt load, and minimizes leakage resulting in greater reliability and performance.

This products offers the following benefits:

- Highly conformable to achieve incredible tightness and long-lasting seal
- Eliminates lead times to prefabricate large, one-piece gaskets
- Overcomes flange deviation
- Easy to ship and store
- Reduces inventory
- Offers quick and easy installation

### **Typical Applications**

#### **Large/non-standard steel equipment flanges:**

Vessel and tank process flanges & manways, large diameter piping, heat exchangers, baffles, columns and mixing tanks, reactors, towers, and turbines

#### **Processes utilizing highly aggressive-media, in:**

- Chemical processing
- Pulp and paper manufacturing
- Mining and minerals
- Semiconductor manufacturing
- Power generation

FOR INDUSTRIAL USE ONLY. Not for use in food, drug, cosmetic or medical device manufacturing, processing, or packaging operations.