



GORE® Filtration Products

Acid-Resistant Aramid Felt
475 g/m² (14 oz/yd²)

DESCRIPTION

A 204 °C (400 °F) maximum service temperature, acid-resistant aramid felt filter bag for use in pulse jet style dust collectors.

FEATURES & BENEFITS

- GORE™ membrane technology provides an excellent combination of filtration efficiency and dust cake release.
- Woven ePTFE scrim offers superior chemical resistance and excellent dimensional stability.
- Unique acid-resistant treatment reduces the detrimental effects of moisture and acids.

APPLICATIONS

- **Chemicals Processing:** Dryer baghouses in the pigment, plastic, and catalyst industries.
- **Minerals Processing:** Dryer baghouses in the gypsum industry and clinker cooler baghouses.
- **Metals Processing:** High temperature process collectors for lead oxide and electric arc furnace baghouses in the steel industry.
- **Power Generation and Incineration:** Fly ash handling collectors

LAMINATE TECHNICAL DATA

Weight	475 g/m ² (14 oz/yd ²)
Fiber Content	100 % Virgin Aramid
Felt Construction	Supported Needlefelt with Acid-Resistant Treatment
Continuous Operating Temperature	204 °C (400 °F)
Maximum Surge Temperature	218 °C (425 °F)
Acid Resistance	Very Good
Alkali Resistance	Good
Breaking Strength	
• Warp	1112 N/5 cm (250 lb/2 in) wide sample
• Fill	1600 N/5 cm (360 lb/2 in) wide sample
Mullen Burst	4653 kPa (675 psi)
Thickness	1.91 mm (0.075 in)
Elongation at 50 lb	
• Warp	2.0 %
• Fill	5.5 %
Flame-Resistance Testing ASTM D 6413-08	
• After Flame	0 seconds
• After Glow	35.1 seconds
• Char Length	1.1 inches

Note: All data expressed as typical values. This technical data is subject to change. Please contact W. L. Gore & Associates, Inc., directly to confirm current information.

FOR INDUSTRIAL USE ONLY. Not for use in food, drug, cosmetic or medical device manufacturing, processing, or packaging options.

GORE and designs are trademarks of W. L. Gore & Associates ©2011–2017 W. L. Gore & Associates, Inc.

W. L. Gore & Associates, Inc.

101 Lewisville Road, Elkton, MD 21922
US Toll-Free: 800.437.5427 • Phone: +1.410.392.3300
Fax: +1.410.506.0107 • E-mail: filterbags@wlgore.com

gore.com/filterbags

