

GORE® High Durability Filter Bag

Woven Acrylic/Polyphenylene Sulfide Fabric 305 g/m² (9 oz/yd²)

Description

A 127°C (260°F) maximum service temperature, woven acrylic/polyphenylene sulfide fabric filter bag for use in shaker style dust collectors.

Features & Benefits

- GORE membrane technology provides an excellent combination of filtration efficiency and dust cake release.
- The complimentary properties of the woven acrylic and polyphenylene sulfide fiber provides enhanced acid and hydrolysis resistance.
- Excellent dimensional stability and flexibility. These properties are necessary for successful cleaning and operation.

Applications

Metals Processing: Baghouses in the lead and base metals production industries.

Power Generation: Baghouses in coal-fired utilities.

Laminate Technical Data

Weight	305 g/m ² (9 oz/yd ²)
Fiber Content	Polyacrylonitrile & Polyphenylene Sulfide
Fabric Construction	2 x 1 Twill
Continuous Operating Temperature	127°C (260°F)
Maximum Surge Temperature	140°C (284°F)
Acid Resistance	Excellent
Alkali Resistance	Good
Breaking Strength	Warp: 779 N/2.54 cm (175 lb/1 in) grab Fill: 1113 N/2.54 cm (250 lb/1 in) grab
Mullen Burst	0.51 mm (0.02 in)
Shrinkage	1.5% x 1.3% nominal

All data expressed as typical values. This technical data is subject to change. Please contact W. L. Gore & Associates, Inc., directly to confirm current information.

All technical information and advice given here are based on Gore's previous experiences and/or test results. Gore gives this information to the best of its knowledge, but assumes no legal responsibility. Customers are asked to check the suitability and usability in the specific application, since the performance of the product can only be judged when all necessary operating data are available. The above information is subject to change and is not to be used for specification purposes. Gore's terms and conditions of sale apply to the sale of the products by Gore.

GORE, *Together, improving life* and designs are trademarks of W. L. Gore & Associates. © 2020–2025 W. L. Gore & Associates, Inc.