

ESCC 3408-QUALIFIED SOLUTION FOR MISSION-CRITICAL SYSTEMS

Microwave/RF cable assemblies must endure the most demanding spaceflight conditions such as harsh launches and landings, temperature extremes, and high levels of radiation that can significantly impact their crucial ability to transmit signals.

Gore brings uniqueness to the industry by utilizing our extensive knowledge and unparalleled expertise in manipulating fluoropolymers to be used in applications above the Earth, above the equator, or in deep space. We manufacture our products with this extraordinary fluoropolymer along with specialized connector termination processes that meet strict industry specifications and have been proven in critical systems now and over time.

Proven Ruggedness and Signal Reliability

GORE® Spaceflight Microwave/RF Assemblies, Type 8S is qualified to ESCC 3408/002 specifications and on the ESA Qualified Parts List (QPL). Our coaxial cable assembly is proven to transmit uninterrupted signals with low loss and excellent phase stability at frequencies ranging from DC to 22 GHz for the duration of the mission (Table 1).

With approved materials, Type 8S is precisely engineered to maintain electrical and mechanical integrity in the harshest environments. The unique jacket material wrapped around our cable assembly is radiation tolerant at 700 MRad, reducing the risk of system damage or failure. Our cable assembly can also tolerate exposure to extreme thermal cycles over time, shock, and vibration.

In addition, Type 8S has a small diameter of 2.2 mm (0.085 in). The low mass and high flexibility of our cable assembly make routing and installation much easier in high-density applications, such as inside-the-box and box-to-box systems.

Program Heritage

For decades, we have provided reliable solutions in hundreds of global spaceflight programs with a 100% failure-free flight record. We work closely with the ESA (European Space Agency) to deliver valued reliability from an ESA-qualified and ISO 9001:2000-certified manufacturing facility.

Our products have been used in many ESA missions — including Aeolus, Biomass, Envisat, ERS, IXV, MetOp, Meteosat, MSG, MTG, Sentinel, and more.



Benefits

- Proven coaxial cable qualified to ESCC 3408/002 and on the ESA Qualified Parts List (QPL)
- Easier installation and reduced mass for inside-the-box and box-to-box applications
- Superior radiation protection due to specialized, high-performance materials
- Eliminate EMI with outstanding shielding effectiveness up to 22 GHz
- Valued reliability delivered from ESA-qualified, ISO9001:2000-certified manufacturing facility
- Decades of 100% failure-free flight record in hundreds of global spaceflight programs

Table 1: Cable Assembly Properties

Electrical

Property	Value
Maximum Frequency (GHz)	22
Standard Impedance (Ohms)	50 ± 1
Insertion Loss dB/m (ft)	
1 GHz	0.63 (0.19)
18 GHz	2.83 (0.89)

Mechanical / Environmental

Property	Value
Jacket Material	Tefzel® ETFE
Braided Shield	Silver-Plated Copper
Conductor	
Outer	Helically Wrapped Foil/Silver-Plated Copper
Center	Solid / Silver-Plated Copper
Dielectric Material	Gore ePTFE
Overall Diameter mm (in)	2.2 (0.085)
Mass g/m (g/ft)	13.1 (4.0)
Minimum Bend Radius mm (in)	
Single	6.4 (0.25)
Multiple	12.7 (0.50)
Radiation Resistance (MRad)	700
Operating Temperature Range (°C)	
Standard	-55 to +150
Qualified	-110 to +150

Ordering Information

GORE® Spaceflight Microwave/RF Assemblies, ESCC 3408-Qualified Type 8S is available with connector variants engineered to complement assembly performance, minimizing loss and reflection (Table 2).

For more information or to discuss your specific application needs, please contact a Gore representative at <http://escies.org/GOREUK>.

Table 24: Connector Variants

Type	Code	Form	Maximum Frequency (GHz)
SMA	S01	Straight Pin	22
	S71	90° Box Pin	22
	ZF8	90° Swept Pin	22
	Y04	90° Clip Pin	22
	S02	Straight Socket	22
	R42	Bulkhead Socket	22

Information in this publication corresponds to W. L. Gore & Associates' current knowledge on the subject. It is offered solely to provide possible suggestions for user experimentations. It is NOT intended, however, to substitute for any testing the user may need to conduct to determine the suitability of the product for the user's particular purposes. Due to the unlimited variety of potential applications for the product, the user must BEFORE production use, determine that the product is suitable for the intended application and is compatible with other component materials. The user is solely responsible for determining the proper amount and placement of the product. Information in this publication may be subject to revision as new knowledge and experience become available. W. L. Gore & Associates cannot anticipate all variations in actual end user conditions, and therefore, makes no warranties and assumes no liability in connection with any use of this information. No information in this publication is to be considered as a license to operate under or a recommendation to infringe any patent right.

NOT INTENDED FOR USE in medical device or food contact applications or with radiation sterilization.

TEFZEL a registered trademark of The CHEMOURS COMPANY FC, LLC.

GORE, *Together, improving life*, and designs are trademarks of W. L. Gore & Associates. © 2019 W. L. Gore & Associates, Inc.

W. L. Gore & Associates (UK) Ltd.

Mariner Drive, Dundee Technology Park, Dundee,
DD2 1JA, Scotland
T: +44 1382 561511 F: +44 1382 561007
gore.com

