

## GORE® Protective Vents

Quality Assurance Testing  
For Adhesive Vents



# INCREASE CONFIDENCE, REDUCE RISK AND AVOID COSTLY REWORK

The GORE® Protective Venting team is committed to providing high-quality products that maximize device performance. With over 20 years of expertise and experience in venting sensitive electronics and sealed devices, we stand behind the quality and performance of each and every vent that is produced from our global manufacturing facilities.

To ensure that our products deliver the performance and reliability that you expect, we conduct various tests and use key performance indicators during vent production.

**The following key performance indicators are monitored as part of the quality assurance testing process:**

- **Airflow**

Airflow is defined as the amount of air that flows through the membrane over a particular time, with a given pressure differential.

- **Water Entry Pressure (WEP)**

The liquid intrusion properties of a vent are measured by what is referred to as the water entry pressure.

### Intermediate Product Testing:

#### 1) Airflow Test

Using an airflow testing system on the membrane leads to a high level of component reliability, because the vents can be evaluated throughout each batch production run. This ensures that the membrane is fully functional and within the specified limits.



**Your benefit:**

This ensures that the specified airflow/venting performance is met for pressure equalization needs.


### Benefits of Quality Assurance Testing During Series Production of GORE® Adhesive Vents

- 100% airflow testing and WEP testing of all membrane rolls
- Valuable information regarding key performance indicators such as airflow, material water entry pressure (WEP) testing and burst strength
- Confidence that the vents meet your application's performance requirements

#### Water Entry Pressure Testing



#### Gurley Airflow Testing



#### 2) Material Water Entry Pressure Test

The material WEP is performed throughout each batch production run to ensure the membrane has been adequately integrated with the backing material, such as the PET non-woven.

**Your benefit:**

This ensures that the membrane is fully supported by the backing material, as necessary, prior to adding the adhesive.

*Together, improving life*



## Finished Product Testing:

### 1) Dimension Testing

The inner diameter (ID) and outer diameter (OD) of each manufacturing lot is measured prior to a full batch production run to ensure the proper specifications and tolerances are met.

#### Your benefit:

This ensures that the ID/OD required for your application needs will have the proper venting area that has been designed into your housing.

### 2) Burst Testing

A burst test is performed on each manufacturing lot after a batch production run to ensure the adequate bond strength between the membrane and adhesive materials are achieved. The product must pass a hold of 0.1 bar for 30 min.

#### Your benefit:

This ensures that the membrane and adhesive have been integrated properly during manufacturing and have the specified strength to meet the IPX7 standard.

### 3) General Visual Inspection

Constant process parameter monitoring during production, as well as regular inspection and maintenance cycles, ensure the high quality of our vents. In addition, the vents are 100% visually inspected prior to final packaging. This manual inspection is done by examining for defects such as cosmetic, concentricity, delamination, and contamination.

#### Your benefit:

With a variety of fitness-for-use defects which can be identified through visual inspection, Gore takes ownership of manually inspecting each vent prior to shipment to ensure the product will meet your quality and application needs.

**Membrane Pin Holes:** A pin hole is a defect which can be caused during processing of the membrane. In many cases, a pin hole resembles contamination on the part, such as dust or dirt. However, with further investigation, it becomes evident that the defect is embedded in the membrane, and a small hole has formed. This can cause a path for water entry and lead to failure.

**Figure 1:**  
**Not acceptable** — pin hole in vent



**Particles on Membrane:** Vent is visibly contaminated with dust, dirt, or particles that cannot be removed.


Contamination with particles > 0.5 mm<sup>2</sup> in the membrane active area may cause the vent to fail. Do not use the part.

**Figure 2:**  
**Not acceptable** — particles > 0.5 mm<sup>2</sup> on membrane that cannot be removed



**Membrane Concentricity:** The vent adhesive, liner, and/or backer appear to be misaligned. For standard adhesive vents less than 25.4 mm in diameter, the acceptable part specification allows for up to a 0.4 mm shift from the center line. If the vent is not within specification, do not use. Contact Gore for concentricity guidance for parts larger than 25.4 mm in diameter.

**Figure 3:**  
**Not acceptable** — center line shift is not within the acceptable tolerance of 0.4 mm



**FOR INDUSTRIAL USE ONLY. Not for use in food, drug, cosmetic or medical device manufacturing, processing, or packaging operations.**

GORE® Protective Vent(s) are manufactured under the generic industrial ISO 9001 quality system. No other certifications can be provided by Gore for this GORE® Protective Vent. All technical information given is based on Gore's previous experiences and/or test results. Gore gives this information to the best of its knowledge, but assumes no legal responsibility. Customers are asked to check the suitability and usability in the specific application, since the performance of the product can only be judged when all necessary operating data are available. The above information is subject to change and is not to be used for specification purposes. Gore's terms and conditions of sale apply to the sale of the products by Gore.

GORE, *Together, improving life* and designs are trademarks of W. L. Gore & Associates. © 2012–2024 W. L. Gore & Associates, Inc.

